

What you should have:



- 1) Open Face Headset (Speakers, Mic, and Windsock)
- 2) 2- Velcro Disc
- 3) 2- Speaker Foam Cover
- 4) Mounting Bracket
- 5) Popsicle Stick

*Shown with Bombardier helmet.

Step 1

Grab your headset. You will notice that your speaker wires are not the same length. The shorter wire is your left speaker and the longer wire is your right speaker. You will also notice that the mounting bracket is built into the microphone. You will need to cut the bracket off the Mic. After cutting the bracket it should look like this (2nd image):

Step 2

Get the helmet. Now carefully remove your left cheek pad. After removing the cheek pad carefully remove the lining and place the speaker inside. Repeat the same step for the right cheek pad. After installing the speakers inside the cheek pads Reinstall the right cheek pad, but leave the left pad out.

Step 3

With the left padding still out you will need to place the microphone between the padding and the shell. To do so you will need double-sided tape or Velcro to hold it in place. With the Velcro holding the microphone in place, reinstall the cheek pad.

Step 4

Now with the speakers and the microphone install, grab the popsicle stick to hide any loose wires along the helmet and make sure the din plug is on left side of the helmet and most important the *microphone in front of your lips.

* (Bombardier) There is two ways to install the microphone. First, you can make a small cut on the breath guard and slip the microphone inside. Second, make no cuts on the breath guard and just place the microphone on the inside, in front of your lips.

* (Schubert/Nolan) Disregard breath guard installation.

