

What you should have:



- 1) Open face headset (speakers & microphone)
- 2) Mounting bracket is connected to the boom microphone
- 3) Popsicle stick
- 4) Velcro/ foam pack
- 5) Helmet wire clips (qty 2)

Step 1

Take the headset and lay it out across the table. Notice one of the two speakers has a shorter cord then the other.

Step 2

The speaker with the shorter end should be mounted on the left side and the other speaker on the right.

Step 3

With this type of helmet you have two ways that you can install the speakers.

- a) use the zip in wind curtain that came with your helmet and Velcro the speakers on the inside of it
- b) Make pockets for the speakers by cutting out two pieces of cloth or leather in the shape of a V. Proceed to sew those pieces over the Vstraps on both sides of the helmet. This will make pockets for you to Velcro the speakers on the inside of them.

Step 4

For mounting the bracket and boom microphone to the helmet
Refer to the instructions for the Full Face mounting bracket and proceed to follow.

Tuck all the left over wires into the lining of the helmet with the Popsicle stick.

Make sure the plug of the headset comes out from the rear left side of the helmet
(you may use the helmet wire clips to hold the wires on the helmet.)

*Not every brand of helmet is the same exact install but with this you should have the basic idea. Feelfree to make small adjustments for your install to work.

