

### What you should have:



- 1) shorter end of bracket
- 2) longer end of bracket
- 3) padded insert
- 4) qty 4 screws
- 5) hex wrench

### Step 1

Take the padded insert and remove the paper strip from the back.

Take the longer end of the bracket and place the padded insert on the inside.

### Step 2

Connect the longer and shorter end of the bracket together.

Choose either the longer or shorter end set of screws depending on the thickness of the shell of your helmet.

Insert the selected screws into the bracket so that both long and short end are held together. ( only insert the screws into the first set of grooves so that you will still have play)

### Step 3

The longer end of the bracket will be on the outside of the helmet and the shorter on the inside.

Slide the bracket up as far as it will go onto the shell of the helmet. (Be sure to locate the bracket on the left side middle portion of the helmet)

### Step 4

Tighten the screws evenly only until the bracket is snug and does not slide across the helmet. ( do not tighten the screws until they stop turning)

