

What you should have:



- 1) Open face headset (speakers & microphone)
- 2) Mounting bracket is connected to the boom microphone
- 3) Popsicle stick
- 4) Velcro/ foam pack
- 5) Helmet wire clips (qty 2)

Step 1

Take the headset and lay it out across the table. Notice one of the two speakers has a shorter cord than the other.

Step 2

The speaker with the shorter end should be mounted in the left side indentation of the helmet with Velcro

Step 3

Mount the other speaker in the right side indentation with Velcro

Step 4

For mounting the bracket and boom microphone to the helmet
Refer to the instructions for the Full Face mounting bracket and proceed to follow.

Tuck all the left over wires into the lining of the helmet with the Popsicle stick.

Make sure the plug of the headset comes out from the rear left side of the helmet
(you may use the helmet wire clips to hold the wires on the helmet.)

This will allow you to bend and tuck the boom microphone under so that it is positioned in front of your lips.

*Not every brand of helmet is the same exact install but with this you should have the basic idea. Feel free to make small adjustments for your install to work.

