

## MOTIVE PRODUCTS APPLICATION GUIDE

(scroll to bottom for adapter ID dimensions, Tilton, Wilwood and Classic British Car applications)

Vehicle Make	Model	Year	Bleeder	Adapter
<b>Acura</b>	All	1985+	0101	1101
			<b>Bleeder</b>	Adapter
<b>Alfa Romeo</b>	All	All	0109/0100**/1101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>AMC</b>	All	1964-1988	0105	1105
			<b>Bleeder</b>	<b>Adapter</b>
<b>Audi</b>	All	All	0109/0100/0101	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>BMW</b>	All	All	0109/0100**/1101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Buick</b>	All	1967-1980	0105	1105
	Century	1973-1984	0105	1105
	Century	1987-2006	0108/0101*	1108/1101*
	GS	1967-1977	0105	1105
	Le Sabre, Park Avenue, Riviera	1991-2001	0108/0101*	1108/1101*
	Reatta	1990	0109/0100**/1101*	1109/1100**/1101*
	Regal	1967-1978	0105	1105
	Regal	1988-1990	0101	1101
	Regal, Skyhawk, Skylark, Somerset, Gran Sports	1991-2006	0108/0101*	1108/1101*
	Roadmaster	1995	0108/0101*	1108/1101*
	Skyhawk, Skylark, Somerset	1987-1991	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
	<b>Cadillac</b>	Allante, Concours, El Dorado, Seville, (w/ABS)	1986-1995	0101
Brougham, Fleetwood		1967-1980	0105	1105
Brougham		1990-1995	0108/0101*	1108/1101*
Cimieron		1987-2006	0108/0101*	1108/1101*
CTS, CTS-V		2001+	0108/0101*	1108/1101*
CTS-V clutch		2004	0100/0109	1100/1109
Deville		1991-2001	0108/0101*	1108/1101*
El Dorado, Concours, Seville		1967-1978	0105	1105
El Dorado		1991+	0108/0101*	1108/1101*
Fleetwood (w/ABS)		1987-1993	0101	1101
Fleetwood (Diesel)		1981-1986	0101	1105
Northstar		1996+	0108/0101*	1108/1101*
Seville SLE, STS		1996+	0108/0101*	1108/1101*
SRX, XLR		2003+	0108/0101*	1108/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Chevrolet</b>	Baretta, Cavalier, Celebrity, Corsica, Caprice	1987-2006	0108/0101*	1108/1101*
	Alero, Blazer	1999+	0108/0101*	1108/1101*
	Camaro	1967-1991		1105
	Camaro	1993+	0108/0101*	1108/1101*
	Caprice, Impala	1967-1980	0105	1105
	Cavalier	1995+	0108/0101*	1108/1101*
	Chevelle, El Camino, Malibu, Monte Carlo, Nova, Vega	1967-1977	0105	1105
	Chevette, Monsa	1975-1987	0105	1105
	Colorado	2004 +	0107/0117/0101	1107/1101
	Corvette	1953-1962	0102	1102
	Corvette	1963-1964	0101	1101
	Corvette	1965-1966	0119	1119
	Corvette	1967-1982	0105	1105
	Corvette	1984-1991	0101	1101
	Corvette	1992-2008	0108/0101*	1108/1101*
	El Camino, Malibu, Monte Carlo (Diesel)	1982-1988	0105	1105
	Impala SS	1994-1996	0105 Metal	1105 Metal
	Lumina, Lumina APV	1995	0108/0101*	1108/1101*
	Lumina (except Z 34 or 1100 Z4)	1990-2001	0108/0101*	1108/1101*
	Malibu	1997-2005	0108/0101*	1108
	Nova	1985-1988	0101	1101
	Spectrum, Sprint	1985-1992	0101	1101
	Silverado, Tahoe, Trailblazer	2000+	0108/0101*	1108/1101*
Transport	1999+	0108/0101*	1108/1101*	
Van P,G	All		1105 (Dual cylinder) none (off set cylinders)	
		<b>Bleeder</b>	<b>Adapter</b>	
<b>Chevrolet, GMC</b>	C, K, R, V 30, 3500	1967-1987	0105	1105
	Sonoma, Suburban, V 10, S10, 1500, 2500	1967-1980	0105	1105
	Suburban, Tahoe	2000	0105	1105
	Suburban, Tahoe	2001+	0108/0101*	1108/1101*
	Sonoma, Suburban, C, K, R, V 10, S10, 1500 (w/metal), Tahoe	1981-1999	0105	1105
	Sonoma S10	1998-2007	0108/0101*	1108/1101*
	Blazer, Caballero, Jimmy	1976-1980	0105	1105
	Blazer, Caballero, Jimmy (Diesel)	1981-1991	0105	1105

	Tracker	1989-1990	0101	1101
	Yukon	1976-1990	0105	1105
	Yukon, XL	1998-2008	0108/0101*	1108/1101*
	Yukon (Diesel)	1981-1991	0105	1105
	Vans (1/2 ton, ¾ ton, 1 ton)	1967-1984	0105	1105
	Vans (3/4 ton, 1 ton) w/ metal reservoir	1985-2001	0105	1105
			<b>Bleeder</b>	<b>Adapter</b>
<b>Chrysler</b>	All	1967-1978	0105	1105
	300M	1999+	0107/0117/0101	1107/1101*
	Concorde LX	1993-1997	0108	1108
	Concorde LX	1999-2002	0107/0117/0101	1107/1101*
	Crossfire	1999-2002	0107/0117/0101	1107/1101*
	Grand Voyager	1999-2001	0107/0117/0101	1107/1101*
	Grand Voyager	2002+	0103	1103
	LHS	1993-1997	0108/0101*	1108/1101
	New Yorker	All	0107/0117/0101	1107/1101*
	PT Cruiser	All	0103	1103
	Sebring	2001+	0107/0117/0101	1107/1101*
	Voyager	LE, LX, SE		1103
			<b>Bleeder</b>	<b>Adapter</b>
<b>Dodge</b>	All except: 1971-1975 Colt	1967-1977	0105	1105
	All w/ metal reservoir	1978	0105	1105
	Charger	1968-1978	0105	1105
	Charger	2006 +	0103/0101*	1103/1101*
	Colt	1971-1975	0101	1101
	Colt (except Colt Mini Van)	1978-2001	0101	1101
	D Series	1967-1980	0105	1105
	Rampage	1982-1984	0105	1105
	Dakota	2001	0107/0117/0101*	1107/1101*
	Durango	1999	0107/0117/0101*	1107/1101*
	Intrepid	1993-1997	0108/01018	1108/1101*
	Magnum	2005-2008	0103	1103
	Neon Sport	1996+	0107/0117/0101*	1107/1101*
	Neon LE, SE	2001+	0103	1103
	Ram 150	1982-1993	0103	1103
	Ram 250	1982-1985	0103	1103
	Ram 350	1981-1983	0103	1103
	Ram 250 w/plastic	1981,86-88	0103	1103
	Ram 250 w/metal	1981,86-88	0105	1105
	Ram 350 w/plastic	1984-1987	0103	1103
	Ram 350 w/metal	1984-1988	0105	1105
	Ram 250, 350	1989-1993	0105	1105
	Ram 1500, 2500, 3500	1994-1997	0105	1105
	Ram 1500, 2500, 3500	1998-2005	0103	1103
	Ramcharger	1974-1989	0105	1105
	Stealth	1991-1996	0101	1101
	Stratus	1999+	0107/0117/0101*	1107/1101*
	Viper, non ABS	1992-2002	0107/0117/0101*	1107/1101*
	Viper with ABS	2001-2008	0103	1103/1101
	W100/150 w/ metal reservoir	1967-1981	0105	1105
	2000 GTX	1978-2001	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
<b>Dodge Van</b>	B Series w/ metal reservoir	1967-1980	0105	1105
			<b>Bleeder</b>	<b>Adapter</b>
<b>Eagle</b>	All	1988-2001	0101	1101
	Vision	1993-1997	0108/0101*	1108/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Ferrari</b>	All	All	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Ford</b>	All w/ metal reservoir	1967-1987	0105	1105
	All except Mystique, Probe '94-'99	1988-2001	0101	1106/1107/ 1101*
	Aerostar	1993+	0107/0117/0101*	1107/1101*
	Contour	All	0109/0100**/0101*	1109/1100**/1101*
	Courier	1972-1982	0109/0100**/0101*	1109/1100**/1101*
	Escort Exp. w/ metal reservoir	1983-1990	0105	1105
	Escape	2005+	0107/0117/0101*	1107/1101*
	Escort	1991+	0107/0117/0101*	1107/1101*
	Explorer	All	0107/0117/0101*	1107/1101*
	Fiesta	1978-1980	0109/0100**/0101*	1109/1100**/1101*
	Focus	All	If a threaded screw on cap 0109/0100**, otherwise 0101*	If a threaded screw on cap 1109/1100**, otherwise 1101*
	Mystique	1994-1999	0109/0100**/0101*	1109/1100**/1101*
	Mustang	Up to 2005	0107/0117 if round cap with three tabs on underside of cap. If two tabs 0106 0105 if rectangular	1107 if cap has 3 tabs. 1106 if cap has 2 tabs 1105 if rectangular
	Mustang	2005+	0108/0118/0101*	1108/1118
	Navigator	2001+	0107/0117/0101*	1107/1101*
	Probe	1994-1999	0109/0100**/0101*	1109/1100**/1101*
	Ranger	1996-1998	0107/0117/0101*	1107/1101*
	Clutch reservoir – if reservoir neck is 45mm in diameter and threaded	1989-2008	0109/0100**/0101*	1109/1100**/1101*

	Taurus	All	0107/0117/0101*	1107/1101*
	F150, F250, F350, F450, F550	1987+	0107/0117/0101*	1107/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Ford Truck</b>	All w/ metal reservoir	1967-1986	0105	1105
	All except Aerostar	1987-2001	0101	1106/1107/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Gen. Motors</b>	All with ITT MkIV ABS	All	0108/0101*	1108/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Geo</b>	Metro	1996-2001	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
<b>Honda</b>	If Master Cylinder Cap is less than 3" in diameter.	1973-2009	0101	1101
	If Master Cylinder Cap is 3" or larger in diameter.	1973-2009	0119	1119
			<b>Bleeder</b>	<b>Adapter</b>
<b>Hyundai</b>	All except Pony, 1992-93 Sonata	1985-2001	0101	1101
	Accent	1995+	0107/0117/0101*	1107/1101*
	Elantra	2001+	0107/0117/0101*	1107/1101*
	Sonata	1995+	0107/0117/0101*	1107/1101*
	Stellar	1985-1987	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>International</b>	All trucks (Light Duty)	1967-1980	0105	1105
			<b>Bleeder</b>	<b>Adapter</b>
<b>Infinity</b>	G35x	All	0107/0117/0101*	1107
	M35x	All	0107/0117/0101*	1107
	All others	All		Please call or email for help
			<b>Bleeder</b>	<b>Adapter</b>
<b>Isuzu</b>	All	1984-2001	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
<b>Jaguar</b>	Daimler Super V8	All	0109/0100**/0101*	1109/1100**/1101*
	S type	1999+	0107/0117/0101*	1107/1101*
	XKR, XJR	1999+	0109/0100**/0101*	1109/1100**/1101*
	X type	2001+	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Jeep</b>	Cherokee, Grand Cherokee, Wagoneer	1967-1980	0105	1105
	Cherokee, Grand Cherokee, Wagoneer w/ metal reservoirs	1984-1992	0105	1105
	Cherokee	1995	0107/0117/0101*	1107/1101*
	Cherokee, Wrangler, Grand Cherokee	1996+	0103	1103
	Clutch if neck is 45mm in diameter and threaded	All	0109/0100**/0101*	1109/1100**/1101*
	CJ, YJ, Comanche	1967-1994	0105	1105
	CJ, YJ, Comanche w/ plastic reservoir	1995-2001	0101	1101
	CJ, YJ, Comanche w/ metal reservoir	1995-2001	0105	1105
	Liberty	2002-2008	0103	1103
	J10, J20	1967-1980	0105	1105
	Wrangler TJ	1997+	0107/0117/0101*	1107/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Kia</b>	Rio	2003+	0107/0117/0101*	1107/1101*
	Sephia, Sportage, Sorento	All	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Land Rover/ Range Rover</b>	All except Discovery II	1970-2001	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Land Rover</b>	Discovery II	2000+	0101	1101
	Series 2, Series 2a	1958-1968	0101	1101
	Series 3	All	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
<b>Lexus</b>	All except some GS	All	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
<b>Lincoln</b>	All	1967-1989	0105	1105
	All	1990-2001	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
<b>Lotus</b>	Elise/Exige	All	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Mazda</b>		121	1995+	0107/0117/0101*
		323	All	0101
		6	All	0108/0101*
	MX6 626 (w/ 1 3/4" screw on reservoir cap)	1979-1999	0109/0100**/0101*	1109/1100**/1101*
	All others	All	0101	1101
	Miata	1 <sup>st</sup> and 2 <sup>nd</sup> Gen Brake	0111	1111
	Miata	1 <sup>st</sup> and 2 <sup>nd</sup> Gen Clutch	0109/0100**/0101*	1109/1100**/1101*
	Miata	3 <sup>rd</sup> Gen	0109/0100**/0101*	1109/1100**/1101*
	MPV	1999+	0107/0117/0101*	1107/1101*
	Protégé	1990-2003	0109/0100**/0101*	1109/1100**/1101*
	Tribute	2001+	0107/0117/0101*	1107/1101*
	RX-7	Third Gen	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Mercedes Benz</b>	All	All	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Mercury</b>	All w/ metal reservoir	1967-1999	0105	1105

	Capri	1971-1977	0109/0100**/0101*	1109/1100**/1101*
	Capri	1979-1985	0105	1105
	Contours	1995-2001	0109/0100**/0101*	1109/1100**/1101*
	Merkur	1985-2001	0109/0100**/0101*	1109/1100**/1101*
	Tracer	1991-1992	0109/0100**/0101*	1109/1100**/1101*
	All others	1988-2001	0107/0117/0101*	1107/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Mini (New)</b>	Cooper/Cooper S	2001+	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Mitsubishi</b>	All	All	0101	1101
	Evolution, EVO 8	2003-2005	0107/0117/0101*	1107/1101*
	Lancer	2003	0107/0117/0101*	1107/1101*
	Outlander	All	0107/0117/0101*	1107/1101*
	All Wagons	1999+	0107/0117/0101*	1107/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Nissan</b>	All	1970-2005	0101	1101
	100 SX	1995+	0107/0117/0101*	1107/1101*
	200 SX	All	0107/0117/0101*	1107/1101*
	350 Z	2003+	0107/0117/0101*	1107/1101*
	Frontier	1999+	0107/0117/0101*	1107/1101*
	Quest	2000+	0107/0117/0101*	1107/1101
	Maxima	1995+	0107/0117/0101*	1107/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Oldsmobile</b>	Achieva	1992-2005	0108/0101*	1108/1101*
	Aurora	1995-2001	0108/0101*	1108/1101*
	Calais, Cutlass Ciera,Firenza	1987-2006	0108/0101*	1108/1101*
	Cutlass, Supreme,Vista Cruiser	1967-1973	0105	1105
	Cutlass, Supreme,Vista Cruiser	1974-1981	0101	1101
	Cutlass, Supreme, Vista Cruiser (Diesel)	1982-1987	0105	1105
	Firenza	1987-1999	0101	1101
	Intrigue	1998+	0108/0101*	1108/1101*
	Omega	1973-1979	0105	1105
	Passport, Optima	1988-1991	0101	1101
	Regency, Royale (Diesel)	1981-1985	0105	1105
	Silhouette	1995	0108/0101*	1108/1101*
	Starfire	1975-1980	0105	1105
	Tornado	1967-1978	0105	1105
	Tornado (Diesel)	1982-1985	0105	1105
	88, 98, Custom, Cruiser, Delta, Regency Royale	1967-1980	0105	1105
	88, 98, Custom, Cruiser, Delta, Regency Royale	1991-1999	0108/0101*	1108/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Peugeot</b>	All	All	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Plymouth</b>	All	1967-1978	0105	1105
	All	1995-2001	0101	1101
	Laser	1990-1993	0101	1101
	Neon	1994-1995	0101	1101
	Voyager	1987	0105	1105
			<b>Bleeder</b>	<b>Adapter</b>
<b>Pontiac</b>	Acadian	1976-1987	0105	1105
	Astre, Beaumont	1967-1978	0105	1105
	Asuna, Sunfire	1992-1999	0108/0101*	1108/1101*
	Bonneville, Catalina w/ metal reservoir	1967-1986	0105	1105
	Bonneville SSE, Bonneville (optional)	1991	0108/0101*	1108/1101*
	Fiero, Firebird, Trans Am	1967-1980	0105	1105
	Fiero, Firebird, Trans Am	1993-2002	0108/0101*	1108/1101*
	Grand Am, Lemans	1976-1980	0105	1105
	Grand Am, Lemans, J2000 Sunfire,Phoenix, Sunbird	1987-1991	0101	1101
	Grand Am	1987-2006	0108/0101*	1108/1101*
	Grand Prix	1967-1981	0105	1105
	Grand Prix (Diesel)	1982-1984	0105	1105
	Grand Prix (except 1994-95 GT)	1988-1999	0101	1101
	Grand Prix	1992-1996	0108/0101*	1108/1101*
	GTO	1964-1978	0105	1105
	GTO	2004-2005	0105	1105
	GTO	2006	0107/0117	1107/1101*
	G8	ALL	0107/0117	1117
	J2000, Sunfire w/ metal reservoir	1976-1980	0105	1105
	J2000 Sunbird	1992-1994	0108/0101*	1108/1101*
	Parisienne, Phoenix, Safari, Sunbird w/ metal reservoir	1976-1980	0105	1105
	Parisienne, Safari (Diesel)	1981-1985	0105	1105
	Sunbird	1987-2006	0108/0101*	1108/1101*
	Sunburst Tempest	1985-1991	0101	1101
	Sundance	1996-1999	0108/0101*	1108/1101*
	Sunfire	1995-1998	0108/0101*	1108/1101*
	Transport Van	1991-1999	0101	1101
	Trans Sport	1995	0108/0101*	1108/1101*

	Ventura 6000	1967-1978 1987-2006	0105 0108/0101*	1105 1108/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Porsche</b>	All	All	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Renault</b>	All	1972-1989	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Saab</b>	All	1972-1994	0109/0100**/0101*	1109/1100**/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Saturn</b>	All SW	1992-2001 1999	0109/0100**/0101* 0103	1109/1100**/1101* 1103
			<b>Bleeder</b>	<b>Adapter</b>
<b>Subaru</b>	All	All	0101	1101
	Forrester	1999+	0107/0117/0101*	1107/1101*
	Impreza	1998+	0107/0117/0101*	1107/1101*
	Outback	1989+	0107/0117/0101*	1107/1101*
	STI	2005	0107/0117/0101*	1107/1101*
	WRX	2001+	0107/0117/0101*	1107/1101*
			<b>Bleeder</b>	<b>Adapter</b>
<b>Suzuki</b>	All	1979-1999	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
<b>Toyota</b>	All, except some late model 4runners (please call)	All	0101	1101
	4Runner	Some	0105	1105
			<b>Bleeder</b>	<b>Adapter</b>
<b>Volvo</b>	All, except S40, V40	1972-2001	0109/0100**/0101*	1109/1100**/1101*
	S40, V40	All	0101	1101
			<b>Bleeder</b>	<b>Adapter</b>
<b>VW</b>	All water-cooled	All	0109/0100**/0101*	1109/1100**/1101*
	All air-cooled except Vanagon 1980+	All	0104**	1104***
	Vanagon	1980+	0109/0100**/0101*	1109/1100**/1101*

\* All vehicles that use the Custom 1100, 1106, 1107, 1108, 1109 adapters can also use the **1101 Universal Round Adapter**.

\*\* Adapters 1109 and 1100 are interchangeable. The 1109 is the latest version with new enhanced features. See description in product listing.

\*\*\*We have come across some VW Bus from the 60s that use the 1100. Please measure the ID of the reservoir. If it is 1 3/4" please order the 1100.

This is not an exhaustive list; our adapters may fit vehicles not listed here. If you do not see your vehicle, please call us at 877-59-BRAKE. We also are looking for owners of cars not listed that are in the SF Bay area that are willing to allow us to test fit a cap in return for a discount.

### WILWOOD AND TILTON APPLICATIONS

WARNING – while the 1100 and the 1109 Cap will mate with the Tilton 74 and 75 series, we have seen in testing that in actuality the cap does not fit properly and can "pop" off the reservoir. Also pressurizing the brake fluid reservoir can result in the reservoir popping off the master cylinder for reservoirs attached directly to the master cylinder if the retaining clamp is not tight. Currently Motive Products recommends using the 1101 cap on the Tilton 74 and 75 series.

Wilwood model #	Power Bleeder model	adapter part # (included in kit)
260-3372	0100**	1100
260-3374	0100**	1100
260-3376	0100**	1100
260-3378	0100**	1100
260-3380	0100**	1100
260-5920	0100**	1100
260-6764	0105*	1105
260-6765	0105*	1105
260-6766	0105*	1105
260-1304	101	1101
260-2636	101	1101
260-6579	101	1101
260-4893	0105*	1105
260-4894	0103***	1103

### TILTON / WILWOOD / STRANGE INFO

1105 adapter or the 0105 bleeder kit works with Tilton series 73, AFKO, and Howe master cylinders.  
1101 adapter or the 0101 bleeder works on Tilton series 74, 75 master cylinders

\*\*\*Also works on Strange master cylinder with Chrysler style reservoir

We do not have an adapter to fit Wilwood 260-8555 or 260-8556

### Classic English Car Applications

Make	Model	Years	Adapter (brake)	Adapter (clutch)
<b>Austin Healey</b>	BN1-BN2	all	1109	1109
	BN4-BJ8	all	1100	1100
	Sprite	1959-67	1110	1110
	Sprite	1968-71	1101**	1110
<b>Austin-Cooper</b>	Mini	1959-73	1110	1110
	Mini	1974-77*	1110	1110
<b>Jaguar</b>	XKE (38)	all	1100	??
	XKE (42)	all	1100	1110
	Mark II	all	1100	1110
	XJ6, XJ12	1968-77	1100	1110
	XJ6, XJ12	1978-87	1101**	1110
	XJ6, XJ12	1988-94	1100	1100
	XJS	1976-88	1101**	none
<b>MG</b>	Midget	1959-67	1110	1110
	Midget	1968-80	1101**	1110
<b>MG T</b>	TC		1109	none
<b>MGA</b>	1500-1600	all	1110	1110
<b>MGB</b>		1962-67	1110	1110
		1968-74	1101**	1110
<b>Triumph</b>	2,3	all	1110	1110
	3-3B	all	1109	1109
	4-4A	all	1101**	1109
	250,6	all	none	1109
	Spitfire	1971-75	none	1100
	Spitfire	1976-80	1100	1100
	7	all	1110	1100
8	all	1110	1100	

\*with single line system

\*\*1101 universal adapter fits 38-81 mm reservoir opening and requires clamping to reservoir with chain and bolt kit provided with adapter

Cap Part Number	Size in MM	Size in Inches	Notes
1100	43.25 mm	1.70	
1101	38-81mm	1.5 to 3.20	lgth 5.19"
1102	31.5mm	1.24	18 threads per inch Male
1103/1113	42 mm	1.65	
1104	27 mm	1.06	
1105	Dim 4.25" x 6.75"	hole spacing 3.5"	
1106/1107/1117	50.5 mm	1.99	
1108/1118	48.43	1.91	
1109	43.3 mm	1.70	
1110	25 mm	0.98	
1111	70.5 mm	2.77	